
Erasing data from graphic calculators for exams

JCQ regulations require that

- the student is responsible for clearing anything stored in the calculator
- the calculator must not have retrievable information stored in it.

All stored data can be erased from the fx-CG50 and fx-CG20 by following a full reset to factory conditions. The procedure is






Graphic calculator Examination Mode

Examination Mode makes the fx-CG50 and fx-CG20 calculators fully compliant with JCQ regulations for use in exams. In particular it disables

- access to user data
- access to Physium (periodic table)

Examination Mode stays active for 12 hours.

Please note that **Examination Mode is not suitable for Further Mathematics** students as it disables vector calculation and 3D graphing. A full reset is recommended for Further Mathematics students. Please see separate instructions "fx-CG50 exam reset".



Exiting Examination Mode

The calculator will automatically exit Examination Mode after 12 hours. For other ways to exit earlier, please refer to the manual.

